


## STANDARD ECONO-CHECK COMPONENTS

For Use With Econo-Check Bases No. 201 & No. 1101 and No. E-101-G-DT.



**NO. 104** V-Block Fixture. 1 1/2" x 4 3/4" drilled and tapped to accommodate fixture attachment. Base slotted for easy adjustment.

**NO. 105** Flat V. 1 1/2". Precision ground finish.



**NO. 106** Parallel Fixture. Note slotted adjustment feature.

**NO. 106-A** Groove Bar for attachment to No. 106 Parallel Fixture.

**NO. 107** 90° Angle Fixture. Slotted for easy adjustment.

**NO. 107-A** Ground Guide Bar. (Size 3/8" x 1 1/2" x 4") For attachment to No. 107 90° Angle Fixture.



**NO. 107-B** Ground Guide Bar. (Size, 3/8" Square x 4") Contains Four 1/4" — 20 UNC Tapped Holes.

**NO. 108-A** Ground Guide Stop. Slotted for easy adjustment. 1 1/4" x 3/4" x 3 3/4". Less Dial Indicator.



Manufacturer and National Distributor

**WM. L. RIGGS, CO. INC.**

600 SOUTH 129th EAST AVENUE • TULSA, OKLAHOMA 74108  
PHONE (918) 437-1174 • FAX (918) 437-1175

## ECONO-CHECK® INSTANT GAGING FIXTURES FOR MULTIPLE CHECKING OF MACHINED PARTS

### INDICATORS

Refer to price list for Indicators stocked for Econo-Check.



#### SPECIAL SHAPED CONTACT POINTS

Special shaped ends on Depths Rods can easily be made for any checking requirement.



### CONTACT POINT ADAPTOR

#### AN ECONOMICAL SOLUTION TO "AWKWARD CHECKING JOBS"

4-48 UNF Thread

**NO. 109**

The Econo-Adaptor allows you to make a "custom" contact point from 1/8" drill rod or 1/8" dowel in your own shop. Use with AGD indicators. No threading necessary. Just slip contact point into adaptor and tighten set screw.



4-40 UNC Socket Set screw

3/8" Dia. hole to accommodate 1/8" drill rod for various lengths and shaped contact points.

### UPRIGHT POSTS

**NO. 102-DT 1" x 24"**

**NO. 102-DT 1" x 18"**

**NO. 102-DT 1" x 12"**

**NO. 102-DT 1" x 9"**

1" diameter ground and polished upright post. Drilled and tapped on the bottom for easy attachment.